

Learning Spaces Support: Visualizer Operation (manual control)

STEP 1 Getting Started

On AV Control Panel

Select 'Visualizer' or 'Doc Cam' as the Source

STEP 2 Set up- On the Visualizer



Press the Power Button



Adjust the Arm as required –
Push away to raise & pull forward to lower*
(*different models may vary)



Place materials onto visualizer

STEP 3 Adjust as required

On the Visualizer



Use controls to adjust – Zoom, Focus or Freeze
(Freeze will freeze the image, deselect button to unfreeze)

STEP 4 When Finished

On the Visualizer



Press the power button
Remember to reselect 'Source' on the AV Control Panel or switch the system off if you have finished